






ACCESS VOICEMAIL

1. Press .
2. When prompted, enter **PIN-Code** and press 
 - For new messages, press .
 - For saved messages, press .
 - For advanced voicemail settings, press .

PLACE CALL ON HOLD/RESUME A CALL

To place a call on hold:

- Press the **Options** soft key during a call, and select **Hold**.

To resume a call, do one of the following:

- If only one call is on hold, press the **Resume** soft key.
- If there are two calls on hold, press the **Resume** soft key to resume the current call. Press the **Swap** soft key to swap between calls.

TRANSFER A CALL

Blind Transfer - The call is transferred directly without the need to announce the caller:

- Press the **Options** soft key during a call, and select **Blind transfer**.
- Enter the number you wish to transfer the call to.
- Press the **Transfer** soft key.

Attended Transfer - Allows you to announce the caller prior to releasing the call

- Press the **Options** soft key during a call, and select **Transfer**.
- Enter the number you wish to transfer the call to.
- Press the **Transfer** soft key to dial out.
- Press **Transfer** after announcing the call to the third-party.

ENABLE CALL FORWARD

To enable Call Forward on a specific line:


- Press the **OK** key to enter the main menu, and select Call Features > Call Forward.
- Press **▲** or **▼** to highlight the desired line, and press the **OK** soft key.
- Press **▲** or **▼** to highlight the desired forwarding type, and press the **OK** soft key.
 - Always----Incoming calls are forwarded immediately.
 - Busy----Incoming calls are forwarded when the line is busy.
 - No Answer----Incoming calls are forwarded if not answered after a period of time.
- Select **Enabled** from the **Status** field.
- Enter number to forward to in the **Target** field and press the **Save** soft key to accept the change.



Yealink W52H IP DECT Phone

Quick Reference User Guide







How to:

REGISTER HANDSET TO W52P BASE STATION

Each W52P base station can register a maximum of 5 handsets each. Each handset can be registered to up to 4 different base stations.

To register your handset manually, do one of the following:


- Long press  on the base station till the registration LED flashes slowly. Then press the OK key to enter the main menu on the handset, select Settings > Registration > Register Handset.
- If the handset LCD screen prompts “Press base page 2s then press OK”, long press  on the base station till the registration LED slow flashes. Then press the OK soft key on the handset, select Register Handset.
 1. Select a base station and press the OK soft key. The handset will initiate the connection.
 2. Press the OK soft key to confirm connection to the base station.
 3. Enter the base station PIN (default: 0000) and then press the Done soft key to complete registration.



If successful, handset will display “Handset Subscribed”. If handset prompts “Searching for Base”, please check your base station is powered on.

TURN HANDSET ON/OFF

To turn handset on, do one of the following:


- Press  until the LCD screen lights up.
- Place handset in the charger cradle. It will then turn on automatically.

To turn handset off:





- Long press  until the LCD turns off.

PLACE/REDIAL A CALL



To place a call directly, do one of the following:

- Enter the desired number when the handset is idle, and press .





To place a call from the local directory:

1. Press  when the handset is idle.
2. Press  or  to highlight the desired entry, and then press .

To redial the last dialled number:



1. Press  when the handset is idle.
2. Press  again to place the call.

To redial a previously dialled number:


1. Press  when the handset is idle.
2. Press  or  to highlight the desired entry, and then press  to place the call.

ANSWER/END/IGNORE A CALL


To answer a call, do one of the following:

- Press the **Accept** soft key.
- Press  or .



To end an active call:

- Press  during an active call.

To ignore an incoming call, do one of the following:

- Press  when an incoming call is presented.
- Press the **Silence** soft key when an incoming call is presented.

LOCK/UNLOCK KEYPAD

- Long press  when the handset is idle to unlock the keypad.
- Long press  again to lock the keypad.

ENABLE/DISABLE SILENT MODE

- Long press  when the handset is idle to enable/disable silent mode.